



- 1) 12mm Promat SUPALUX® fillets fastened to the faces of the supporting members with screws or nails. The width of the fillets are such that they will overlap each supporting member 5mm on each side.
- 2) 12mm Promat SUPALUX® board fixed to the ends of the roof members using 50mm nails at nominal 200mm centres or 50mm x No.8 woodscrews at nominal 300mm centres. Fixings required along top and bottom edges.
- 3) Rockpanel fixed to the ends of the roof members in accordance with Rockpanel's recommendations.
- 4) 12mm Promat SUPALUX® board fixed to the underside of the roof members using either 50mm nails at 200mm centres or 50mm x No.8 woodscrews at nominal 300mm centres.
- 5) Timber noggings or dwangs to form a continuous backing plate along the front and back edge of the soffit. Both the vertical and horizontal sections of the Promat SUPALUX® should be affixed to these noggings using the fixings described above. Minimum section size 50mm x 50mm. (50mm x75mm behind Rockpanel joints).
- 6) Mineral wool insulation laid over Promat SUPALUX®. Minimum density 60mm thick x 60kg/m³.
- 7) Timber roofing members at maximum 610mm centres. These can be at reduced centres (i.e. 400mm) with no adverse effect on the fire performance of the proposed system.
- 8) Alternative roofing member for flat roof construction. Joists at maximum 610mm centres.

AUTHORITY: BRE Assessment report number: CC207951

Technical Data Sheet – 004

Page 1 of 1
(Dec 2003)



Promat UK Limited
 Technical Services Department
 The Sterling Centre, Eastern Road
 Bracknell, Berkshire RG12 2TD
 Tel: 01344 381 400
 Fax: 01344 381 401
 E-mail: technicaluk@promat.co.uk

